

# Installation guide of swivel

Step 1 - Unscrew seat from seat base

Step 2 - Put the swivel between seat and seat base as shown below.

Step 3 - Firstly screw swivel to the seat base, then screw the seat. Use bolts detailed in table (next sheet)

Step 4 - If the model requires it, install the emergency brake adapter or height adjustment adapter.



VEHICLE	CODE	SIDE	MOUNTING KIT 1	MOUNTING KIT 2	MOUNTING KIT 3
Ford Transit	OBT10001	Driver	4x DIN 7991 Bolt M8x20-10.9 4x ISO 7092 Washer M8 4x DIN 985 Self-locking Nut M8	4x DIN 7991 Bolt M8x20-8.8	3x DIN 7991 Bolt M8x20-10.9 3x DIN 933 Bolt M8x20 - 8.8 6x DIN 985 Self-locking Nut M8
	OBT10004	Passenger	4x DIN 7991 Bolt M8x20-10.9 4x ISO 7092 Washer M8 4x DIN 985 Self-locking Nut M8	4x DIN 7991 Bolt M8x20-8.8	-
Mercedes-Benz Sprinter 906	OBS10001	Driver	4x DIN 7991 Bolt M10x20-10.9 4x DIN 985 Self-locking Nut M10	4x DIN 7991 Bolt M10x20-10.9	2x DIN 7991 Bolt M10x20-10.9 2x DIN 933 Bolt M10x20-8.8
	OBS10004	Passenger	4x DIN 7991 Bolt M10x20-10.9 4x DIN 985 Self-locking Nut M10	4x DIN 7991 Bolt M10x20-10.9	-
Mercedes-Benz Sprinter 907	OBV10001	Driver	4x DIN 7991 Bolt M10x25-10.9 4x DIN 985 Self-locking Nut M10	4x DIN 7991 Bolt M10x35-10.9	2x DIN 7991 Bolt M10x20-10.9 2x DIN 933 Bolt M10x20-8.8
	OBV10004	Passenger	4x DIN 7991 Bolt M10x25-10.9 4x DIN 985 Self-locking Nut M10	4x DIN 7991 Bolt M10x35-10.9	-
Volkswagen Crafter	OBC10001	Driver	4x DIN 7380 Bolt M10x20-10.9 2x DIN 125 Washer M10	4x DIN 7991 Bolt M10x25-10.9	-
	OBC10004	Passenger	4x DIN 7380 Bolt M10x20-10.9 2x DIN 125 Washer M10	4x DIN 7991 Bolt M10x25-10.9	-
Volkswagen T6	OBA10001	Driver	4x DIN 7991 Bolt M8x20-10.9 4x DIN 985 Self-locking Nut M8	2x original seat base bolt M8 4x original seat base nut M8 2x DIN 7991 Bolt M8x20-10.9	2x DIN 933 Bolt M8x25-8.8 2x ISO 4032 Nut M8
	OBA10004	Passenger	4x DIN 7991 Bolt M8x20-10.9 4x DIN 985 Self-locking Nut M8	2x original seat base bolt M8 4x original seat base nut M8 2x DIN 7991 Bolt M8x20-10.9	-
Fiat Ducato	OBF10001	Driver	6x DIN 7991 Bolt M8x35-10.9 6x DIN 985 Self-locking Nut M8	6x DIN 7991 Bolt M8x20-10.9	-
	OBF10004	Passenger	6x DIN 7991 Bolt M8x35-10.9 6x DIN 985 Self-locking Nut M8	6x DIN 7991 Bolt M8x20-10.9	-

VEHICLE	CODE	SIDE	MOUNTING KIT 1	MOUNTING KIT 2	MOUNTNIG KIT 3
Renault Trafic	OBO10001	Driver	4x DIN 7991 Bolt M10x18-10.9 4x ISO 4032 Nut M10	4x DIN 7991 Bolt M10x60-10.9	-
	OBO10004	Passenger	4x DIN 7991 Bolt M10x18-10.9 4x ISO 4032 Nut M10	4x DIN 7991 Bolt M10x25-10.9	-
Maxus Deliver 9	OBM10001	Driver	4x DIN 7991 Bolt M8x20-10.9 4x ISO 7092 Washer M8 4x DIN 985 Self-lockin Nut M8	4x DIN 7991 Bolt M8x20-8.8	-
	OBM10004	Passenger	4x DIN 7991 Bolt M8x20-10.9 4x ISO 7092 Washer M8 4x DIN 985 Self-lockin Nut M8	4x DIN 7991 Bolt M8x20-8.8	-

Vehicle	Version	Side	Swivel handle location
Ford Transit	GB	Driver	Front
		Passenger	Front
	EU	Driver	Front
		Passenger	Front
Mercedes-Benz Sprinter 906	GB	Driver	Left
		Passenger	Right
	EU	Driver	Right
		Passenger	Left
Mercedes-Benz Sprinter 907	GB	Driver	Left
		Passenger	Right
	EU	Driver	Right
		Passenger	Left
Volkswagen Crafter	GB	Driver	Left
		Passenger	Right
	EU	Driver	Right
		Passenger	Left
Volkswagen T6	GB	Driver	Left
		Passenger	Right
	EU	Driver	Right
		Passenger	Left
Fiat Ducato	GB	Driver	Left
		Passenger	Right
	EU	Driver	Right
		Passenger	Left
Renault Trafic	GB	Driver	Left
		Passenger	Right
	EU	Driver	Right
		Passenger	Left
Maxus Deliver 9	GB	Driver	Front
		Passenger	Front
	EU	Driver	Front
		Passenger	Front